

## The Shooter

Designed and crafted under exacting German quality standards, the Shooter is the all encompassing bag for your shoot. Composed of the finest 1680D ballistic nylon to give you extra durability, and six other layers to ensure your camera is well protected, the Shooter can withstand the rigours of a busy production shoot and the weight of all the kit that comes with it.

When you go on a shoot, the last thing you want is numerous bags and cases. The Shooter can fit your camcorder as well as the accessories that come with it (batteries, lens, small lights, tape) and side pockets to take lightweight tripods or stands. Detachable padded dividers and removable interiors mean you can customize the main compartment in whichever way you want.

Large enough to hold your camera / camcorder and accessories and compact enough to take as handcarry luggage\*, the Shooter is the only bag you will need.

## Specifications

<b>Weight</b>	3.18kg (7lbs)
<b>Dimensions (exterior)</b>	H54cm x W38cm x D34cm (21.25" x 15" x 13.4")
<b>Extended Dimensions (exterior)</b>	H54cm x W38cm x D41cm (21.25" x 15" x 16.15")
<b>Laptop Compartment (interior)</b>	H40cm x W26cm x D4cm (15.7" x 10" x 1.5")
<b>Construction</b>	Composed of seven layers: 1680D Ballistic Nylon High Density Foam Polyester Lining Polyurethane Foam Polypropylene Board High Density Foam Fleece Lining
	Bottom of bag made of heavy duty 1800D Nylon
<b>Colours Available</b>	Black

\* Unextended size. Please check with individual airlines for hand carry size allowances.

[www.genustech.tv](http://www.genustech.tv)

Distributor / Dealer

# GENUS



## The Shooter


professional camera backpack

The Shooter

**Name Card Slot**  
For easy identification

**Soft Handle**  
Wide soft handle for comfortable grip

**Carabiner Hooks**  
Rigorously tested to hold up to 68kgs per hook. Clips onto the shoulder straps to give better support and balance



**Phone Pouch**  
Includes a detachable phone pouch large enough to fit wide phones and has a small opening at the bottom to accommodate earphone usage



**Back of Bag**  
The Shooter's back panel has a built-in flap for trolley use. It can be unzipped to reveal the back pack harness system. The panel can then be attached to the main compartment cover to act as additional padding for your kit



**Raincover**  
Waterproof raincover can be used in adverse weather conditions. Attached to bag to prevent loss and stored in its own zip pocket on the underside of the bag



**Side of Bag**  
With partial elasticated mesh pockets and clasp strap to hold long items such as tripods and additional zipped pockets with snap button tabs. Featured on both sides of the bag



**Adjustable Shoulder Straps**  
For height adjustment and comfort

**Back Padding**  
Breathable contoured mesh padding to give back support and keep you dry

**Expandable Chest Strap**  
With built in elasticated strap to ease the constriction on your chest

**Coin/Card Pockets**  
Extra pockets on waist belt to store small flat items. With snap button zip tabs

**Waist Belt**  
Comfortable waist belt with durable clasps. Excess strap length can be neatly tucked behind the coin/card pockets

**Snap Button Tabs**  
All outside zippers feature snap button tabs. The three main compartments have lockable zip tabs for extra security

**Reflective Panel**  
Nomex® reflective panelling for easy identification in low light conditions

**Waterproof Zips**  
Durable covered water resistant zips to keep out rain and dirt

**Bottom of Bag**  
Made from 1800D Nylon for extra durability. Comes with four extra long dome feet to reduce drag and friction on bottom of bag (not shown)



**Main Compartment**  
Comes with nine detachable padded dividers in 4 different sizes and two long straps, all with Velcro® attachments for customized sectioning

**Middle Compartment**  
Designed to hold your laptop (up to 15"), paperwork and books

**Front Compartment**  
Made to hold your personal items: wallet, credit cards, passport, pens, keys, etc.



**Expanded Main Compartment**  
The Shooter's main compartment can be expanded by another 7cm (2 3/4")